



human touch®
massage chairs


ht 2720



The HT-2720 is the perfect bridge between state of the art technology and the ancient healing art of massage.

It lets you customize your massage using a wide variety of massage modes with three shoulder height adjustments. The HT-2720 replicates the four primary techniques of professional massage therapists; rolling kneading, compression, and percussion. The HT-2720 will fit most any decor; choose from a soft leather-like material or a plush faux-suede in a wide variety of colors.

features




RELIEF ZONE

Flip back the head pillow to reveal a 'relief zone', a unique feature that allows for a penetrating deep-tissue cervical massage.




ERGONOMIC CONTOUR BACK

Ergonomic contours provide exceptional comfort and back support with or without engaging the Human Touch Robot. This ensures that the HT-2720 is a comfortable chair to sit in; even when you are not getting an invigorating massage.



STEALTH MOUNTED POP-OUT CUP HOLDER


Finger tip released, Pop-out Cup Holder provides instant refreshment support.



PANORAMIC SWIVEL BASE WITH TRANSPORT ROLLER

Chair rests on a swivel base that rotates left and right. A transport roller on back of the base allows for mobility.

More Features For More Comfort




FEATURES:

- 3 Pre-set wellness programs
- Quad roller robot allows for a long massage track
- Panoramic swivel base with transport roller
- Convertible on-board docking controller
- Easy to use remote control
- Pop out cup holder

Model number:

- 100-2720-001: Black-PU
- 100-2720-003: Eggplant-FSU
- 100-2720-006: Cashew-PU
- 100-2720-005: Green-FSU
- 100-2720-004: Cashew-FSU



MESSAGE CONTROLLER – It's all at your fingertips

Position (up/down arrows) – Use these buttons along with one of the stationary massage modes, to set the massage rollers to the desired position on the backrest.

Select an **Auto Program** to relieve your neck/shoulders, refresh your full back, or release your lower back tension, using a variety of massage modes.



Stop – Stops the massage and parks the massage rollers at the top of the backrest.

Range – Press to customize your vertical massage range for maximum comfort. Extend the massage range upward into the Relief Zone for a unique neck massage, or focus it on your lower back. It's up to you!

- Extended – extends your massage into the Relief Zone.
- Standard (default) – focuses your massage below the Relief Zone.
- Low – concentrates the massage in the lower portion of your back.

Zone – Press to further tailor your massage by focusing it on a three-inch zone. After selecting this feature, use the Position buttons to position the massage rollers to your target area.